

FES-087-1 アルミ蚊取り豚 ミニ

この度は、スノーピーク製品をお買い上げいただき、誠にありがとうございます。本製品は、蚊遣器です。安全にご使用いただくためにも下記の取扱説明書をよく読んでからご使用ください。また、読み終わった後も大切に保管してください。説明内容で理解出来ない点及び製品に不具合が確認された際には直ちに使用を中止しご購入いただきました販売店様もしくは弊社ユーザーサービスまでお問い合わせください。

セット内容 (各部の名称)



本体



取扱説明書
(本書)

スペック

- 材質: 胴体／アルミニウム、脚・耳・尾パーツ／ステンレス、吊り金具／ステンレス、下げ紐／綿
- 本体サイズ: 95×96×107 (h) mm
- 重量: 75g

安全上の注意事項 ご使用の前によく読んで予測される事故を回避し安全にご使用ください。

⚠ 危険 明らかに生命に関わる重大な事故が予測される行為を示します。

- 燃焼中の蚊取り線香の取扱いには十分ご注意ください。特に紙やビニール等の燃えやすいものを近づけないでください。火災の原因になります。



⚠ 警告 取扱いを誤った場合、使用者が死亡または重傷を負う可能性があることを示します。

- ご使用前に、本製品を点検し各部に異常がないことを確認してください。異常が発見された場合は、直ちに使用を中止しお買い求めいただいた販売店様、または弊社ユーザーサービス係に点検または修理を依頼してください。
- 本製品は火を扱います。乳幼児の手の届く場所には置かないでください。また、細かいパーツがあるためケガや窒息の危険があります。
- 使用する蚊取り線香を点火後、炎が消えていることを必ず確認してください。炎がついたままで使用すると、火災の原因になります。
- 使用後は蚊取り線香の火が完全に消えていることを確認し、本体が十分に冷えてから移動・収納してください。
- 本製品は置用です。吊り下げてのご使用はできません。
- 蚊取り線香が燃焼中は本製品を激しく揺らしたり動かさないでください。また、持ち歩かないでください。
- 本製品を使用する際は、平たんで安定した場所に設置してください。本体が転倒しないことをよく確認してから使用してください。
- アレルギー体質の方は使用に注意が必要です。蚊取り線香の使用方法をよくお読みください。

⚠ 注意 ケガや本体破損、物品破損として拡大損害の原因となる行為を示します。

- 本製品は蚊遣器です。蚊取り線香以外のものを装着しないでください。
- 本製品の上にものを置かないでください。また収納時はものに挟まれないよう注意してください。
- 蚊取り線香以外のものを中に入れないでください。
- 本製品に蚊取り線香を取り付ける際は手袋などの保護具を使用して下さい。保護具を使用しないと、蚊取り線香の燃焼している箇所が胴体に接触しないよう注意してください。
- 落下の衝撃で変形するおそれがあります。取扱いにはご注意ください。
- 屋内やテント内など締め切った環境で使用すると目やのどに刺激を感じることがあります。使用中はよく換気をしてください。
- 製品本体の耳、脚、しっぽ、下げ紐を持って持ち上げたり移動しないでください。製品の落下及び破損のおそれがあります。
- 脚・耳・尾パーツを胴体から取り外さないでください。
- 吊り下げ金具がゆるくなった際は、手で締めてください。

使用方法



- ②着火する際は吊り金具に確実に固定されていることを確認し、吊り金具を持ち上げてから線香の端部に柄の長いライターなどで着火してください。蚊取り線香に火が付いている間(煙が出ている間)は目を離さないでください。また火のついた蚊取り線香が蚊取り豚本体に接触しない様に注意してください。本体が熱くなりやけどのおそれがあります。

- ③使用後、残った灰は本体が冷えていることを確認してから蚊取り豚のおしりから直接ゴミ袋に捨ててください。

- ①蚊取り線香は図のように渦の中心部分を吊り金具にはさみ吊るしてください。線香の端部が下側になるように吊るすと着火しやすく安全に使用できます。

メンテナンスについて

- 長期間ご使用しなかった製品を再度お使いになる際は、本製品を点検し各部に異常がないことを確認してください。異常が発見された場合は、直ちに使用を中止しお買い求めいただいた販売店様、または弊社ユーザーサービス係に点検または修理を依頼してください。
- 本体を洗浄する場合は固い素材やたわし、クレンザー、磨き粉等を使用しないでください。キズの原因になります。
- 湿気のない乾燥した場所で保管してください。
- 雨等により濡れてしまった場合はやわらかい布等で水分をふき取ってください。
- 製品の外観上洗浄しにくくなっております。洗浄する際は手袋などの保護具を使用して洗浄してください。
- ご使用后、内側に付着したヤニは食器用洗剤を使ってスポンジ等でこまめに洗ってください。ヤニは長期間放置すると取りにくくなります。

品質保証について

お買い求めいただきました製品は万全を期していますが、万一不備な点がございましたら、お買い求めいただいた販売店様もしくは弊社または各製品に記載された連絡先にご相談ください。製造上の欠陥が原因の場合は無償で修理または交換させていただきます。その他の場合は適切な価格で修理させていただきます。修理、交換の判断は弊社の裁量によるものとさせていただきます。また、以下の場合には修理できない場合もありますので予めご了承ください。1. 素材の経年劣化による損害など商品の寿命 / 2. 改造および粗雑な取扱いによる故障 / 3. 取扱説明書で禁止されている取扱いによる故障 / 4. 不測の事故による商品の故障 / 5. その他製造上の欠陥以外による製品の故障 / 6. ゴミやさびによる故障 / 7. 分解したことによる不具合の発生または破損 / 8. 落下やその他の衝撃による部品の変形や破損による不具合 / 9. 摩擦によるパーツの変化及びそれによる故障 / 10. 他社製品との組み合わせによる故障

修理について

- 本格的な修理が必要な場合は、お買い求めになった販売店様または弊社ユーザーサービスまでお問い合わせください。
- 修理を依頼される場合は、必ず十分に乾燥させ、汚れをきれいに落としてください。
- 修理品には修理箇所がはっきりと解るように、必ずメモまたは荷札を付けてください。また破損時の状況をできるだけ詳しく書いたメモを添えてください。
- 修理品の運賃並びに修理費については以下のように規定させていただきます。1. 保証対象の場合: 往復運賃並びに修理費は弊社にて負担いたします。 / 2. 保証対象以外の場合: 往復運賃並びに修理費は、お客様のご負担とさせていただきます。

不明な点やお気付きの点がございましたら、販売店様または弊社ユーザーサービスまでお問い合わせください。

スノーピークユーザーサービス
☎ 0120-010-660 (9:00~17:00)
Email: userservice@snowpeak.co.jp

株式会社スノーピーク
〒955-0147 新潟県三条市中野原456
Tel. 0256-46-5858 / Fax. 0256-46-5860
www.snowpeak.co.jp

MADE IN CHINA

FES-087-1 Mosquito Pig Coil Mini

Thank you for purchasing a Snow Peak product. This product is a mosquito coil holder for camping. For safety, read the following instruction manual before use. Please keep it safe for future reference. Finally, if you find anything that you do not understand in the description or any problems with the product, please stop use immediately and contact the retailer or Snow Peak Customer Service.

Contents (Name of the Parts)



Mosquito coil holder



Instruction Manual
(This Manual)

Specifications

- Materials: Body / Aluminum, Legs / Ears / Tail Parts / Stainless Steel, Metal Hanger / Stainless Steel, Strap / Cotton
- Size: 95×96×107(h)mm / 3.7"×3.8"×4.2"(h)
- Weight: 75g / 2.6 oz

Safety Precautions: Before use, please read thoroughly to ensure safety and avoid accidents.

⚠ DANGER / Misuse could easily result in a serious accident or death.

- Please be careful when handling lit mosquito coils. Keep them away from flammable materials such as paper and vinyl. Careless handling may result in fire.


⚠ WARNING / Misuse could result in serious injury or death.

- Before using the product, check each part for abnormalities. If there are abnormalities, take the product to the dealer or Snow Peak Customer Service for inspection or repair.
- This product handles fire. Keep this product out of the reach of infants. Also, because of the small parts, there is a risk of injury and choking.
- After igniting the mosquito coils, make sure that the flame is extinguished. If you use the product with a flame, it may cause a fire.
- After use, make sure that the fire of the mosquito coil is completely extinguished. Move and disassemble the product once it has cooled sufficiently.
- This product is designed to be used on a tabletop or stable surface. Do not hang.
- Do not shake or move this product while the mosquito coil is burning. Please keep the product stationary when the coils are lit.
- When setting up and using this product, please choose a flat and stable place. Ensure the product does not tip over before or during use.
- Those with allergies should be cautious when using this product. Please carefully read the instructions for the mosquito coils.

⚠ CAUTION / Misuse could result in injury to the user and/or damage to property.

- This product is a mosquito coil holder. Please do not use it for anything other than mosquito coils.
- Do not put anything on top of this product. Be careful not to get caught in objects when storing.
- Please do not put anything other than mosquito coils inside.
- Use gloves or other protective equipment when attaching the mosquito coils to this product. Failure to use protective equipment may result in unexpected injury.
- Use this product with spiral mosquito coils with a diameter of approximately 7cm(2.7") and a thickness of approximately 3.5~4mm(0.14"~0.16") (sold separately). Do not use any other sizes of mosquito coils.
- Be careful not to let the burning part of the mosquito coil touch your body.
- Please handle it with care because the product may be dented if dropped.
- If you use this product in a closed environment, such as indoors or in a tent, you may feel irritation in your eyes and throat. Please only use it in a well-ventilated area. Do not hang objects on the pig's legs or ears.
- Do not lift or move the product by its ears, legs, tail, or strap. Doing so may cause the product to be dropped or damaged.
- Do not remove the legs, ears, or tail from the body.
- If the hanging bracket becomes loose, tighten it by hand.

Instructions for Use



- ① Please hang the mosquito coils with the center of the vortex between the metal hangers, as shown in the figure. Hang it so that the end of the incense stick is on the bottom so it can be used safely and easily ignited.
- ② When lighting the coil, confirm that it is secured to the metal hanger, lift up the metal hanger, and ignite the end of the incense stick with a long-handled lighter. Please do not take your eyes of the product while the mosquito coil is lit and smoke is coming out. Also, please be careful not to let the lit coil touch the main body of the product. The product may become hot and may cause burns.
- ③ After use, please make sure that the main body is cool and throw away the remaining ash directly into the garbage bag from the bottom of the product.

Maintenance

- Before using a product that has been in storage for a long time, check each part for abnormalities. If there are abnormalities, take the product to the retailer or contact Snow Peak Customer Service for inspection or repair.
- When cleaning the main body, do not use hard materials, scrubbing brush, cleanser, or polishing powder. It may cause damage.
- Store in a dry place.
- If it gets wet due to rain, wipe off the moisture with a soft cloth.
- This product is difficult to clean due to its unique shape. When cleaning, use gloves and other protective equipment.
- After use, please wash the dirt on the inside with a sponge using dishwashing detergent. If you hide the tar for a long time, it becomes difficult to take it off.

Warranty

Snow Peak has taken all possible measures to ensure every product is durable and functions correctly. If you find any product defects, please contact the retailer where you purchased the product or Snow Peak Customer Service. If there are apparent defects in the product's manufacturing, the defective product will be repaired or exchanged free of charge. In other cases, Snow Peak will repair the product for an appropriate fee. The decision to repair or replace the product will be at our discretion. Snow Peak will not repair the product for any damage that occurred due to the following: 1. Material deterioration caused by age. / 2. Damage caused by modifications or rough handling. / 3. Damage caused by inappropriate use not mentioned in the instruction manual. / 4. Damage caused by unexpected accidents. / 5. Any damage other than defects in the manufacturing process. / 6. Damage caused by dust or rust. / 7. Damage and defects caused by dismantling the product. / 8. Damage and defects caused by dropping, jolting or other shocks. / 9. Deterioration or failure of parts due to friction. / 10. Damage caused by the use of the product in combination with another manufacturer's products.

Repair

- If professional repairs are required, please contact the retailer where you purchased the product or Snow Peak Customer Service.
- When you request repairs, please make sure that the product is dry and clean.
- Please attach a memo or a tag indicating the necessary repair and please write details of how and when the damage occurred.
- Transportation and repair costs are determined as follows: 1. Within warranty: The transportation cost (both ways) and repair cost will be covered by Snow Peak. / 2. Outside warranty: The transportation cost (both ways) and repair cost will be covered by the customer.